


PC / Workstation




RS232 COMPORT



RVP530

B - Terminal



Synchronous RS530 Port

